



**NAPCO**

**FOUR WHEEL DRIVE  
FOR  
FORD TRACTORS  
600&800 SERIES**

**SERVICE PARTS**

**NAPCO INDUSTRIES, INC.**

**AXLE DIVISION**

**Seventh Street, North Lyndale  
Minneapolis, Minnesota**




# FOUR WHEEL DRIVE

FOR

## FORD TRACTORS

### 600&800 SERIES



**NAPCO AXLE DIVISION**

**NAPCO INDUSTRIES, INC.**  
Seventh Street, North Lyndale  
Minneapolis 11, Minnesota

**NPD 384**

PROCEDURE FOR ORDERING SERVICE PARTS

To assure proper handling and filling of each customers service parts order, without error or delay, supply Napco with the following information:

- A - Tractor model number (example - 640)
- B - Tractor serial number (located on transmission housing above starter)
- C - Type of transmission (4 or 5 speed)
- D - Front axle model and serial number (shown on metal plate which is located on the top of the front axle differential)

